

Connecting of the preheater

- preheater should be connected as factory recommended
- sensor **Tg** mount between preheater and recuperator

